

**IMPORTANT! Read all instructions carefully before beginning installation or drilling of the sink.**

## Installation Instructions for Top-Mount ESS Sinks

1. Place sink in desired location and mark drain opening on countertop.
2. Make a 4-6" cutout for drain assembly. The cutout has to be just large enough so that the drain assembly can be tightened directly onto the sink. If faucet is to be mounted to sink, allow clearance for supply lines.
3. Check for correct drain location by temporarily placing sink on counter.
4. Remove sink from counter and install the drain and faucet assemblies.
5. Apply a small bead of clear silicone or matching tub and tile caulk to the bottom edge of the sink and secure to countertop.
6. Place the sink onto the desired location and allow silicone to cure.
7. Connect the supply lines and drain pipes; then test for leaks.

## Installation Instructions for Semi-Recessed ESS Sinks

1. Place sink in desired location, mark drain and outer edge of sink.
2. Remove sink from counter and draw a new line 1/2"-3/4" inside outer edge of sink; this will be your cutout.
3. If faucetry will be installed on the sink, drill appropriate sized hole(s) for valve(s) using a standard hole saw. Drill from the bottom until the pilot bit pierces through the top surface of the sink, then continue drilling through top to finish holes.
4. Install drain and faucet.
5. Apply a small bead of clear silicone or matching tub and tile caulk to the recessed edge of the sink and secure to countertop.
6. Place the sink onto the desired location and allow silicone to cure.
7. Connect the supply lines and drain pipes; then test for leaks.

## Installation Instructions for Wall-Mount Brackets

1. When ordering a wall-mount bracket, the back wall of the sink will come with 4 or 6 pre-drilled holes (depending on sink size) to facilitate installation.
2. Sufficient wall structure reinforcement must be in place to support the weight of the sink. Please note distance from floor to attachment point of sink in your backer board material.
3. Finish as usual, using sheetrock, tile or other solid-surface material.
4. Hold mounting bracket against wall to determine position of pilot holes and pre-drill for mounting hardware.
5. Place bracket inside edge of sink. Line sink and bracket up to pre-drilled holes in wall. Using the appropriate hardware, mount sink to reinforced wall structure.