



Deluxe Bicycle Chair


C9175T

© Universal Companies, Inc. 2004
All rights reserved for copyright purposes.

No reproduction by print or photocopies allowed without written permission.

Bicycle Chair Assembly

1. Unpack the box. Inspect the parts and report any damage to the shipper and/or Universal Companies at 1-800-558-5571.



2. Insert the **Pneumatic Cylinder** into the top of the base with the “clip” end downwards. Press down firmly.



3. Remove the plastic from the chair seat.
4. The hardware to move the raise and lower the chair is already installed for right-handed operation. If you want to be able to operate the lever with your left hand, turn the chair seat upside down and remove the mechanism with an adjustable wrench or socket. Rotate it 180° and reinstall.



5. To install the back of the chair, remove the knob on the bottom of the seat.
6. Remove the plastic from the chair back and from metal piece attached to the back of the chair.



7. Insert the metal piece into the slit in the leather on the bottom of the seat. Insert it as far as it will go.
8. Replace the knob and tighten it.



9. Lift the assembled chair and place it on top of the pneumatic cylinder, inserting the cylinder into the opening in the seat. Press down firmly on the seat. Weight or applied pressure will serve to “pressure seal” these components.



10. The assembly of your chair is now complete.
Enjoy!

To operate the chair:

- ❑ To raise the seat, pull the lever up while standing.
- ❑ To lower the seat, pull the lever up while seated.

Specifications

Seat – 20” wide, 14.5” front to back.

Back – 14” wide x 9” high

Height range – 22.5” to 28”

5 caster base



Authorized Technical Service Center:

Universal Companies, Inc.

18260 Oak Park Drive

Abingdon, VA 24210

Phone: 1-800-558-5571

Fax: 1-800-237-7199

E-Mail: info@universalcompanies.com

