



## Pneumatic Massage Stool Assembly Procedure

1. Confirm that all parts shown are included.
2. Insert wheels into wheel base. Seating them securely may take some force. Place wheel base on the floor, wheels down.
3. Place the black metal end of the pneumatic cylinder into the round opening in the top of the stool base, silver end up. Use minimal force to secure the cylinder into the base.
4. Place cylinder sleeves over stem. Starting with smallest to largest cylinder.
5. Place button end of the pneumatic cylinder into the opening in the seat tube. Carefully sit down on the seat, until the cylinder locks into place.



## Pneumatic Massage Stool Assembly Procedure

1. Confirm that all parts shown are included.
2. Insert wheels into wheel base. Seating them securely may take some force. Place wheel base on the floor, wheels down.
3. Place the black metal end of the pneumatic cylinder into the round opening in the top of the stool base, silver end up. Use minimal force to secure the cylinder into the base.
4. Place cylinder sleeves over stem. Starting with smallest to largest cylinder.
5. Unscrew the star knob from the bottom of the seat, insert short end of seat bracket, replace and tighten knob.
6. Unscrew the star knob from the rear of the backrest, insert long end of the bracket, replace and tighten knob.
7. Place button end of the pneumatic cylinder into the opening in the seat tube. Carefully sit down on the seat, until the cylinder locks into place.