



INSTRUCTIONS FOR USE

- ① Insert the handle in the groove, moving upwards.
- ② Ensure that the voltage indicated under the base corresponds with that of the network.
- ③ Unscrew the cap (fitted with a safety-valve). Fill the apparatus with distilled water, using the funnel. Screw on the cap.
- ④ The water should never reach the brim of the water-gauge (allow for half a centimeter).
- ⑤ Shallow cup : for the solution to be atomized (handle side).
- ⑥ Shallow cup : to recover the droplets coming from the condensation.
- ⑦ Connect the apparatus to the power socket.
- ⑧ Make contact with the luminous signal switch.
After two to three minutes, the steam will bring the atomizing solution in its wake. Test by hand that the atomization is proceeding regularly. If a few droplets of condensation form on the safety-valve, do not be alarmed. During use, hold the atomizer tilted back slightly. Switch off the current a few moments before atomizing is finished.
- ⑨ When atomizing proceeds irregularly or if droplets of water are splashed, clean the ejectors by inserting the fine metallic plunger.

NOTE

Check the water level; when this has dropped low, add more water. The apparatus should then be cooled off slightly. In order to prevent scale from forming in the apparatus, it is important to use soft water, distilled or mineral water, VOLVIC for example. Empty the apparatus if it has not to be used for several days. At the beginning an unpleasant smell may be given off; this will diminish after it has been used a few times. The usual precautions should be taken as required for all types of electrical equipment. HOLO-ELECTRON is in no way responsible for any damage caused by improper or careless use of the atomizer, a lack of maintenance, or for repairs or transformations made outside of its workshops.

MAINTENANCE

- For cleaning the atomizer, use the same descaling powder as that used for electric coffee-pots.
 - Dissolve one tablespoonful of scale-remover in very hot water (i.e. the equivalent of two shallow cupfuls).
 - Empty the atomizer and fill it with this solution; leave it for 15 minutes without heating.
 - Then clean the ejectors and all the parts where scale has formed by means of a brush dipped in the solution.
 - Empty the apparatus.
 - Rinse it at least three times; fill the apparatus with water and proceed to an atomization without using it for skin care.
- This maintenance should be done regularly.

IMPORTANT

When filling the apparatus, use distilled or soft mineral water (For example : VOLVIC).