

OPERATING INSTRUCTIONS

WARNING: Do not use this table warmer unless it is spread to full size. Failure to follow instructions could cause overheating and possible risk of fire or injury. Read the installation instructions above before operating.

1. After the warmer has been installed, push the on/off button to turn the control on. The control has 10 settings from "L" to "H". Upon the first power up the control will start at a setting of "L" (low). Pushing on the up arrow will increase the control to a warmer heat setting. The control automatically pre-warms the massage table at full power for a period of time that is related to the setting, no need to preheat at a high setting.
2. The control is equipped with a backlight that comes on for 10 seconds after the user turns on or adjusts the setting and then turns off. The backlight turns off to save power and to provide an undisturbed sleep environment.
3. Be patient. It may require several minutes to warm your massage table. The warmer must be covered to trap the warmth or it may seem not to be heating. The pad may feel cool to your hand, but it will be warm when you lie on it. See 4 below.
4. The control(s) may be adjusted to regulate the warmth. Adjust the control up or down one number at a time until you find the desired temperature setting. The control will hold that heat setting in memory after turning it off, or after the 10 hour auto off, and will be the default setting the next time the control is turned on. The exception is if there is a power outage or the plug is removed from the outlet, then you must reset the heat setting.
5. Do not expect to feel warmth at settings below 2 unless the room is cold.
6. Test your warmer only when it is installed, covered, and the control is set at "H". If the warmer is not covered, heat will escape rapidly and the warmer may not feel warm to your hand even though it is operating properly. All warmers are thoroughly tested before being packaged. Be sure the plug makes a good connection in the outlet.
7. The control is equipped with an **automatic 10 hour shut-off**. After 10 hours of continuous use the warmer will shut off. To turn the control back on press the on/off button.
8. The control is equipped with a safety feature that will prevent heating in an unsafe condition and will read "F" when in that mode. If this occurs, turn control off and check the engagement of the cord to the pad. After re-engaging the connector, turn the control back on. If "F" still appears on the control then a failure has occurred and the pad should not be used.

WASHING INSTRUCTIONS

Wash-Do Not Dry Clean. Dry cleaning solvents will damage the warming pad wiring. Wash your warming pad, following all instructions carefully. Be sure to disconnect the control cord before washing.

Do Not

- Use bleach or dry cleaning fluids.
- Twist or wring vigorously.
- Use a wringer.
- Iron mattress pad.
- Use mothballs or sprays.
- Turn mattress pad "on" until it is completely dry.

Machine Wash

- Fill washer with warm water and add minimum amount of All-purpose detergent.
- Agitate to dissolve detergent.
- Measure bedding before washing.
- Add bedding and soak for five (5) minutes.
- Agitate for two minutes.
- Spin.
- Fill with cool rinse and agitate for one minute.
- Spin.

Machine Dry

- Do not use commercial dryers or dryers at your local Laundromat.
- Dry warmer in automatic dryer on high heat for five minutes only.
- Remove warmer while still damp and gently block to original size and drape to finish drying.
- Do not iron your bedding.

Hand Wash

- Wash in mild, soapy water.
- Squeeze soapsuds through a few times.
- Rinse in fresh water.

Line Dry

- Do not use clothes pins.
- Air-dry over two parallel lines. Warmer may be hung over a shower rod if parallel lines are not available.
- Gently stretch to original size.



Electric
Mattress Pad
35NH

Made & Serviced By:
Patented Products, Inc.
Box A, 513 Market Street
Danville, OH 43014

800-990-4622

MT'S