


the melting pot™

UNIVERSAL WAX & SUGAR WARMER



SPILO 
MELT
WORLDWIDE

Congratulations on your purchase of The Melting Pot Universal Wax & Sugar Warmer. Designed for heating all professional warm depilatory products in plastic or metal containers, this state-of-the-art warmer has a thermostatically-controlled heater. It offers a wide range of temperatures (25° C to 60° C and 77° F to 140°F), easy-to-read temperature control, and indicator lights. You can count on The Melting Pot for correct, reliable heat for every depilatory product, every need.

The Melting Pot's stylish Euro design makes it a beautiful and safe salon accessory, with a protective locking lid for sanitary protection and handle for portability. The flared base adds stability and can also be used as a collar, plus it's removable for easy cleaning. The metal container lifter keeps fingers far from heat source and has an ideally-positioned scraper bar.


Your new Melting Pot Universal Wax & Sugar Warmer is designed to last, to provide a safe and portable heater, and to add flair to your salon.

The Melting Pot is ideal for use with all professional warm and hot depilatory products.


We recommend No-Tweeze Original Stripless Wax and No-Tweeze Natural Soft Body Wax.



Removable base
doubles as a wax
collar



Easy-to-read temperature
control with indicator
lights



Convenient
Lifter/Scraper bar
included

INSTRUCTIONS FOR USE

- Remove the warmer lid and place one protective collar directly into the heating chamber. Wax in plastic containers will take longer to heat than that in metal containers. It is recommended that The Melting Pot be switched on approximately one half hour before treatments are due to begin, to ensure the wax or sugar has reached the correct temperature and consistency.
- Plug in the appliance and press on-off switch to confirm The Melting Pot is operative. Red light indicates power is on.
- Move the temperature regulator control clockwise to setting suitable for the product you are warming. The thermostat indicator light will remain illuminated until the required temperature has been reached; then the thermostat will automatically switch The Melting Pot off and on to maintain the chosen heat setting.
- To increase temperature, move the regulator control clockwise; to reduce temperature, move the regulator counter-clockwise.

CAUTION:

BOTH WARMER AND WAX/SUGAR GET HOT. ALWAYS TEST HOT WAX OR SUGAR ON A SMALL AREA OF SKIN BEFORE APPLICATION.

TO PROLONG THE LIFE AND EFFECIENCY OF THE MELTING POT:

- Never pour wax or sugar directly into the heating chamber. Always insert the product in its original container into the unit. Use the can holder for the large 16 oz. cans of wax.
- Always use protective heat collars (use disposable collars or the adaptable base) to minimize the risk of wax spillage entering the heating chamber, and to keep your warmer clean.
- In the event of wax or sugar spillage entering the heating chamber, always thoroughly clean out with a clean cloth when the warmer has cooled after use, using a liquid cleaner specifically formulated for wax removal.

CLEANING THE MELTING POT

- The Melting Pot should be cleaned with a liquid cleaner specifically formulated for wax removal. This will maintain The Melting Pot in optimum condition if used regularly.
- Do not use any other solvents or cleaning products as they could damage the heater and produce toxic fumes when the unit is operating.
- Wax spilled on the plastic exterior of The Melting Pot should be removed as soon as possible. If the wax is allowed to harden, removal is more difficult. It is especially important to keep the on/off switch and temperature regulator control knob free of wax.

CAUTION:

HOT WAX OR SUGAR CAN BURN SKIN. BOTH WARMER AND WAX/SUGAR GET HOT.

DO NOT USE BEFORE READING ALL INSTRUCTIONS CAREFULLY

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should be followed for the safety of all persons.

DANGER

As with most electrical appliances, electrical parts are electrically live even when the switch is off.

To reduce the risk of death by electric shock:

- Always unplug unit immediately after using.
- Do not use while bathing.
- Do not place or store warmer where it can fall or be pulled into tub or sink.
- Do not put or drop unit into water or liquid.
- If unit falls into water, unplug it immediately. Do not reach into water.

WARNING

To reduce the risk of Burns, Electrocutation, Fire, or Injury:

- Read all instructions before using.
- Always test hot wax on small area of skin before using.
- If wax is too hot, it can cause burns.
- This unit is HOT when in use. It can burn unprotected skin.
- Do not touch hot metal surfaces of warmer.
- Use only on flat solid non-tipping surface.
- Never pour wax or sugar directly into heating chamber.
- Do not plug in unit where the power cord can be tripped on or snagged.
- Do not leave unit on overnight or when unattended.
- If wax begins to smoke, unplug unit and have it checked.
- Do not use in bathrooms, or around wet floors or tubs of water.
- Do not immerse in water or other liquids.
- Unplug from outlet when not in use. Allow to cool before handling, cleaning or storing.
- Close supervision required when used by, on or near children or invalids.
- Use unit only for the intended use as described in the instruction booklet.
- Do not use attachments not recommended by the manufacturer.
- Familiarize yourself with warnings and instructions which accompany the wax.

Read All Instructions Before Using.