

## Operating Instructions for Whirlpools Equipped with Fill-Flush® Cleaning System

MTI's Fill-Flush® and Simple Touch® have set the standard for self-cleaning whirlpool systems and still remain unparalleled in the industry. By their nature, whirlpool plumbing lines have a tendency to harbor soap residue, body oils, dirt and water deposits. Both Fill-Flush and Simple Touch clean the internal whirlpool plumbing system including water and air lines, point-massage jets and pump in less than 5 minutes and with less than 10 gallons of water, keeping the bath clean and hygienic. Neither cleaning system is recommended for use with micro-jet clusters or neck jet pillows.

The whirlpool system should be cleaned periodically. MTI Whirlpools recommends cleaning at least once a month, not to exceed 90 days between cleaning. Always use caution when using chlorine-based products in conjunction with other cleaning products. The possibility of harmful fumes could result. Always rinse thoroughly.


Do NOT leave the unit unattended during cleaning system operation.

### To Fill the Bath Equipped with Fill-Flush

- Make sure all jets are in the OPEN position by TURNING the jet nozzles.
- Turn on hot and cold water to desired temperature. Wait about 10 seconds before closing the drain. (This will enable any built-up residue from periods of non-use or from the previous bath to flush out the system and down the drain).
- Fill the tub to the desired level (at least 1" above the highest jet), turn the water off and enjoy your bath.

### To Operate the Fill-Flush Cleaning System

- After bathing, drain the tub as usual, leaving the drain open.
- Close all jets by TURNING the jet nozzles.
- Unscrew the detergent dispenser cap (generally located between the hot and cold handles) and slowly pour detergent into the dispenser. MTI recommends using 2 oz. of MTI Fresh Wave cleaning solution. You may also substitute 1 cup of vinegar or a few drops of a low-sudsing liquid detergent mixed with 1 cup of warm water. Replace the detergent dispenser cap.
- Turn on the hot and cold water (do NOT turn pump on) and let the water run for about 3 minutes.
- Water and detergent will mix together and be routed through the air lines, water lines and pump, out the suction and down the drain. (Some water will still be coming out of the jets.)
- Turn off the water.
- Open the jets and let the remaining fresh water flow out of the jets. The tub is ready for next use.



NOTE: The Fill-Flush system allows water to fill the bath through the whirlpool jets, so there is no need for the traditional filling spout; only hot and cold valves. Simple Touch, on the other hand, requires the use of a filler spout of choice and provides the added benefit of automatic operation.

Patent No. 5383239