CLEANING THE NAIL DRYER:

- Since the nail dryer is made of a heavy-duty steel construction it can be cleaned with a liquid cleaner.
- Do not use any other solvents or cleaning products as they could damage the fans and UV lights and produce toxic fumes when the unit is operating.
- Two powerful enclosed motors will help keep dryer free of debris and extend product life.
- Polish on the exterior of Thermal Spa should be removed as soon as possible with polish remover.

Three Year Limited Warranty

We warrant this appliance to be free from manufacturing defects for 3 years from the original purchase. If the appliance fails due to a manufacturing defect during the warranty period:

RETURN the appliance directly to the factory. Enclose a check or money order for a\$7.00 (U.S.) to cover return postage and handling. The appliance will be replaced or repaired and returned to you.

This **WARRANTY VOIDED** if instructions enclosed are not followed or if the appliance is damaged through abuse, or misuse, by tampering, or by use with unauthorized attachments.

LIMITATIONS: Liability under this warranty is limited to repair or replacement of the appliance as previously described. This warranty gives you legal rights and you may have other rights, which vary from state to state.

AFTER WARRANTY EXPIRES: For repair, you may return the appliance postpaid directly to the factory, at the address given, with your check or money order for \$7.00 (U.S.) to cover the cost of postage and handling. An estimate of the cost to repair will be mailed to you for approval before any work is done.

Thermal Spa Products, Inc.

2035 Factory Lane Petersburg, VA 23803 Phone (804) 732-8300 Fax (804) 732-8395 www.thermalspaproducts.com



Professional Nail Dryer Steel Construction

Instruction Manual

Congratulations on your purchase of the Thermal Spa Professional Nail Dryer. Designed for drying all professional manicures. This state-of-the-art dryer offers a 6- minute complete drying cycle. You can count on Thermal Spa for correct, reliable drying for all your beauty needs.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed for the safety of all persons, including the following:

READ ALL INSTRUCTIONS BEFORE USING

Danger – As with most electrical appliances, electrical parts are electrically live even when the switch is off.

TO REDUCE THE RISK OF DEATH BY ELECTRICAL SHOCK:

- 1. Always "unplug it" when not in use.
- 2. Do not use while bathing.
- 3. Do not place or store appliance where it can fall or be pulled into tub or sink.
- 4. Do not place or drop into water or other liquid.
- 5. If an appliance falls into water, "unplug it" immediately. Do not reach into the water.

WARNING:

To reduce the risk of burns, electrocution, fire, or injury, to persons:

- 1. Read all instructions before using.
- 2. Do not touch hot metal surfaces on the dryer.
- 3. Use only on flat solid non-tipping surface.
- 4. Do not plug in unit where the power cord can be tripped on or snagged.
- 5. Do not use in bathrooms, or around wet floors or tubs of water.
- 6. Do not immerse in water or other liquids.
- 7. This is a professional product and should be used by only professionals!
- 8. Use this appliance only for its intended use as described in this instruction booklet.
- 9. Do not use attachments not recommended by the manufacturer. They may cause hazards.
- 10. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged in any manner or dropped in water. Return unit to the manufacturer.
- 11. Keep the cord away from hot or heated surfaces.
- 12. Keep hands away from fan at all times.
- 13. Do not use outdoors, or operate where aerosol (spray) products are being used. Do not operate where oxygen is being adminstered.
- 14. Do not use the machine for extended periods of time.
- 15. Do not attempt to disassemble unit if experiencing complications. Return for repair.

SAVE THESE INSTRUCTIONS.

INSTRUCTIONS FOR USE:

- After desired application is completed, press the easy on button, and gently place hands on bottom tray. This will begin a 6-minute drying cycle.
- The first two minutes will be fan only. Two heavy duty fans provide a cool swirling air current that quickly removes the thinners in polish to speed the during process without bubbling or smudging.
- The next three minutes will be fan and UV light. This process is the most critical step since it delivers both combinations. The Ultraviolet light turns on with heat to further dry the polish for a smooth finish.
- The last minute will again switch to fan only. This is the final step that will seal your manicure.
- Please refrain from any hand movement during your drying cycle.

The final result is an incredible hard, Smooth, glossy finish manicure in less time, that will last longer.

Model PAR400 - Black Nail Dryer

Heavy-duty steel construction.

❖ Power Source: Plugs into wall outlet 110V AC.

❖ Size: 13" x 15 ¾ x 13 ¼.

❖ Weight: 35 lbs

Warranty: 3 Years

CAUTION: MOVING FANS CAN CAUSE SERIOUS INJURIES. KEEP HANDS AWAY FROM FANS AT ALL TIMES.