

## CLEANING THERMAL SPA:

- The appliance should be cleaned with a liquid cleaner specifically formatted for wax removal.
- Do not use any other solvents or cleaning products as they could damage the heater and produce toxic fumes when the unit is operating.
- Wax spilled on the exterior of the appliance should be removed as soon as possible. If the wax is allowed to harden, removal is more difficult. It is especially important to keep knob free from wax.

## THERMAL SPA ONE YEAR LIMITED WARRANTY

American International Industries warrants this appliance to be free from manufacturing defects for one (1) year from the date of the retail purchase invoice. If the appliance fails due to a manufacturing defect during the warranty period:

RETURN the appliance directly to the factory. The appliance will be replaced or repaired and returned to you free of charge.

This WARRANTY is VOID if the enclosed instructions are not followed or if the appliance is damaged through abuse or misuse, by tampering, or by use with unauthorized attachments. The warranty does not cover consumable parts.

LIMITATIONS: Liability under this warranty is limited to repair or replacement of the appliance as described above. This warranty gives you specific legal rights, and you may have other rights, which vary from state to state.

To claim any products on the warranty, please contact American International Industries at [www.aibeauty.com](http://www.aibeauty.com) or call Customer Service at 800-621-9585.

[www.thermalspaproducts.com](http://www.thermalspaproducts.com)

American International Industries

Los Angeles, CA 90040

All (UK) Ltd. Berkshire RG1 7SR

Thermal Spa® is a registered trademark of All

Printed in China

# Thermal Spa®

Elite Wax Warmer – PAR300/Item # 49120

Economy Wax Warmer – PAR302/Item # 49121

Elite Double Wax Warmer – PAR305/Item # 49122

## Instruction Manual

Congratulations on your purchase of the Thermal Spa Wax & Sugar warmer. Designed for heating all professional warm and hot depilatory products. This state-of-the-art warmer has a thermostatically controlled heater. It offers a wide range of temperatures, easy-to-read temperature control and indicator light. You can count on Thermal Spa for correct, reliable heat for every depilatory product.

## IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed for the safety of all persons, including the following:

### READ ALL INSTRUCTIONS BEFORE USING

**Danger** – As with most electrical appliances, electrical parts are electrically live even when the switch is off.

## TO REDUCE THE RISK OF DEATH BY ELECTRICAL SHOCK:

1. Always unplug the warmer when not in use.
2. Do not use while bathing.
3. Do not place or store appliance where it can fall or be pulled into tub or sink.
4. Do not place or drop into water or other liquid.
5. If an appliance falls into water, unplug it immediately. Do not reach into the water

### WARNING:

To reduce the risk of burns, electrocution, fire, or injury, to persons:

1. Read all instructions before using.
2. THIS UNIT IS HOT WHEN IN USE, IT CAN BURN UNPROTECTED SKIN.
3. Always test hot wax on small area of skin before using.
4. If wax is too hot, it can cause burns.
5. Do not touch hot surfaces of warmer.
6. Use only on a flat, solid, non-tipping surface.
7. Do not plug in unit where the power cord can be tripped on or snagged.
8. Do not leave unit on overnight or when unattended.
9. If wax begins to smoke, unplug unit and have it checked.
10. Do not use in bathrooms, or around wet floors or tubs of water.
11. Do not immerse in water or other liquids.
12. Unplug from outlet when not in use. Allow to cool before handling, cleaning, or storing the appliance.
13. This is a professional product and should be used by professionals only!
14. Use this appliance only for its intended use as described in this instructional booklet.
15. Do not use attachments not recommended by the manufacturer. They may cause hazards.
16. Familiarize yourself with the warnings and instructions, which accompany the wax.
17. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged in any manner, or dropped in water. Return unit to the manufacturer.
18. Keep the cord away from hot or heated surfaces.
19. Do not use outdoors, or operate where aerosol (spray) products are being used. Do not operate where oxygen is being administered.

### SAVE THESE INSTRUCTIONS

### INSTRUCTIONS FOR USE:

- It is recommended that the appliance be switched on approximately one hour before you are due to begin, to ensure the wax or sugar has reached the correct temperature and consistency.
- Insert the wax or depilatory product in its original container into the unit. Loose wax may also be used in the well.
- When using the double unit, the knob settings for the left & right side may not be in the same position to give identical temperatures.
- Max setting is for quick melt only.
- Plug in the appliance and turn the control knob clockwise (to the right) until the indicator light turns on to confirm the warmer is operative. The thermostat indicator light will remain illuminated until the required temperature has been reached; then the thermostat will automatically switch off and on to maintain the chosen heat setting.
- When the appliance is first turned on, you may notice a slight odor. This is normal and will dissipate.
- To increase temperature, move the control knob clockwise; to reduce temperature, move the regulator counter-clockwise. Note: In the off position, unit may be on for a short time to stabilize thermostat.
- Once depilatory is melted, it may be maintained at a lower temperature. Please refer to wax/depilatory manufacturer's specific instructions for use.
- To keep your wax warmer clean, wax collars and wax savers may be purchased separately.

### THERMAL SPA WARMERS & ACCESSORIES

- PAR300/Item #49120 – Elite Wax Warmer
- PAR305/Item #49122 – Elite Double Wax Warmer
- PAR302/Item #49121 – Economy Wax Warmer
- PAR335/Item #49137 – Wax Savers 2-pack
- PAR350/Item #49160 – Wax Collars 50-pack

**CAUTION: HOT WAX OR SUGAR CAN BURN SKIN. BOTH WARMER AND WAX/SUGAR GET HOT. ALWAYS TEST HOT WAX OR SUGAR ON SMALL AREA OF SKIN BEFORE APPLICATION.**