

# **INSTRUCTION MANUAL**

Master Massage Oil Warmer



## **MHP International**

8360 Rovana Circle Sacramento, CA 95828

USA

WEBSITE: www.mastermassage.com


TEL: 1-888-710-7206

EMAIL: customerservice@mhpinternational.com



Mark °C or °F depends on the difference of US and Europe Market

Thank you for purchasing Master® Massage 3-Bottles Oil Warmer. It will provide a quick and efficient way to warm up your massage oil, massage cream, and massage lotion. Please read the instruction manual before operating this device.



# **Specifications**

Items Model	Rated Capacity (W)	Input Voltage(V)	Rated Frequency (Hz)	Max. Working Temperature. (°C/°F)
	125-150W	220V-240V E.U, U.K, A.U & Asia	50-60Hz	60°C/140°F
HOH3 PRO	125-150W	100-120V for U.S.	50-60Hz	

## **Main Dimensions**

N	Ο.	Name	Unit	Dimension (mm/inch)	
	1	Massage Oil Bottle (Diameter×Height)	inch/mm	Ø2"X6"/ Ø50.8 X 155mm	
	2 Massage Oil Warmer Body (Length×Width×Height)		inch/mm	10.7" X 4.7" X 8.9" 270 X 120 X 225mm	

## **Important Warning**



DO NOT pour the liquid directly into the warmer; please fill the bottle with massage oil, massage cream or massage lotion before inserting into warmer's body.



To extend the life of the product, only massage oil, massage cream or massage lotion are recommended to be heated in this warmer.



To avoid electrical shock and fire hazard, make sure the Massage Oil Warmer inside dry and without any residue; keep the massage oil bottle outside clean and dry before use. DO NOT immerse the Massage Oil Warmer in water.



DO NOT supply power to this heater until you have verified that the bottle is in position and filled with at least half a bottle of massage oil. Note that if the bottle is too full, the liquid may leak out due to the expansion during warming; meanwhile, if the bottle is sealed, deformation may occur due to the contraction when it cools.



Turn off the Massage Oil Warmer when it is not in use and before unplugging. DO NOT unplug or touch the inside of the Massage Oil Warmer when it is working.



If the unit is broken, please contact your supplier for certified repair. Please do not try to repair or disassemble it by yourself.



This appliance can be used by children aged from 3 years and above if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.



Cleaning and user maintenance shall not be made by children unless they are aged from 8 years and above and supervised. Keep the appliance and its cord out of reach of children aged less than 3 years.



Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance.



If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.



This appliance is intended to be used in household and similar applications such as:

- staff kitchen areas in shops, offices and other working environments;
- farm houses;
- by clients in hotels, motels and other residential type environments;
- bed and breakfast type environments.



Warning: Potential injury from misuse.



The heating element surface is subject to residual heat after use.

## **Instructions for Use**

### Step1:

Place the warmer on a stable and leveled surface and plug it in. Ensure the plug is dry and clean before plugging in.

#### Step2:

Fill the bottle with massage oil, massage cream or massage lotion and place the filled bottle in the warmer. (Fig. 1)

#### Step3:

Turn on "Power Switch" to the temperature you need. The indicator light will be lightened. Wait 15 to 20 minutes for the oil to come to the desired temperature. (Fig. 2)

#### Step4:

Test the massage oil temperature before use to avoid potential burns. Turn the power switch to "off" when the massage oil is heated to the desired temperature. (Fig. 3)

 For safety, always test the temperature of the massage oil before applying and make sure the client feels comfortable with the temperature.







## **Maintenance Instruction**

This Massage Oil Warmer is a precision electrical instrument. Please handle it with care. DO NOT clean the warmer with water or wipe the unit with wet towel. DO NOT drop the unit or subject to sharp impact. Keep power off when not in use. Always keep your warmer in dry surroundings.