



Maglamp Arm Adjustment for Facial System Lamps



**LOCATE THE COVER
SCREW AT EACH
JOINT ON THE LAMP
AND REMOVE THE
JOINT COVERS.**



**LOCATE THE SMALL
PHILIPPS SCREWS
UNDER EACH COVER
AND SLOWLY TIGHTEN
EACH ONE JUST UNTIL
THE ARM STAYS IN
PLACE. REPLACE EACH
COVER. (Do not Over
Tighten)**