
Aromatic Economy Steamer

Many estheticians consider the facial steamer the most important piece of equipment in the esthetics industry. It is used as part of facial treatments, and is frequently used with oxygen products. Warm, humid mist has several benefits including:

- □ Softens dead cells on the surface of the skin so they can be exfoliated more easily.
- □ Aids in opening pores so they can be properly cleansed.
- Penetrates deep into the pores to soften blackheads and deposits of grease, makeup, and dirt so that the debris can be easily removed.
- □ Causes blood vessels to expand, increasing blood circulation
 - Assists the pores in eliminating toxins
 - Provides nourishment to the skin
- □ Softens superficial lines temporarily.
- □ Assists in the penetration of other products.

Parts/Accessories





Operations/Precautions

FOR PROFESSIONAL USE ONLY

To reduce the risk of electric shock:

- □ Always unplug the Aromatic Economy Steamer when not in use.
- Do not use while bathing.
- Do not place (or drop) into water or any other liquid.
- Do not reach for a unit that has fallen into water. Unplug immediately.

To reduce the risk of burns, electric shock, fire, or injury:

- Do not leave the Aromatic Economy Steamer unattended when in use.
- Do not allow children to operate the Aromatic Economy Steamer.
- □ Extreme caution should be used when Aromatic Economy Steamer is used on or near invalids.
- □ The Aromatic Economy Steamer should be used only for its intended purpose as described in this manual.
- Do not use attachments that are not recommended by the manufacturer.
- Do not operate the Aromatic Economy Steamer if:
 - It has a damaged cord or plug.
 - If it is not working properly.
 - If it has been dropped or damaged.
 - If it has been dropped into water.

- □ If damaged, return the Aromatic Economy Steamer to an authorized service center for examination and repair.
- □ Keep the cord of the Aromatic Economy Steamer away from heated surfaces.
- Do not use the Aromatic Economy Steamer outdoors.
- □ Connect the Aromatic Economy Steamer to a properly grounded outlet (preferably a GFCI outlet).

Known Contraindications

There may be unknown contraindications for this Product. For this reason, you should always recommend that your Client discuss the use of this Product as part of their spa treatment program with their health care professional before commencing treatment. Universal Companies, Inc., its officers, directors, employees and vendors cannot be responsible for any claims, damages, injuries or expenses arising from your Client's use of this Product prior to discussing it with their health care professional or from disregarding the Product's instructions, and you and your Client agree to hold Universal harmless from any such claims. We and our suppliers care about the health and beauty of your Clients. While we make every reasonable effort to maintain strict quality control and training standards, every client is unique and spa treatments do affect people differently. Unless you advise us otherwise, we have to assume that your Client has discussed your spa treatment plan with their health care professional and secured their approval. Doing this will make your Client's spa experience safe and will be supportive of their overall emotional and physical well being. After all, that is the goal of us all.

Instructions for Use

Prior to the Onset of Treatment

- 1. To fill with water:
 - Remove the Steamer Fill Cap and add distilled water to the upper red line.
 - The lower red line marks the low water level. When water drops to that line, add more water.

Caution: Do not add cold water to a hot steamer jar. The jar will break.

The Aromatic Economy Steamer is equipped with a protective device. When the element gets too hot and/or if the water level gets too low, the steamer will shut down to protect the unit.

- Replace the Steamer Fill Cap.
- 2. Plug the steamer into an approved GFCI outlet.
- 3. The On/Off Switch located on the left-hand side of the panel controls the Ozone. When the Ozone is operating the Ozone Lamp light will be lit.
- 4. To start the production of steam, turn the Power/Timer Dial clockwise pass the 10 minute mark. Allow 8 to 10 minutes for steam to start being produced.

How to operate the Aromatic Economy Steamer during a treatment

1. After the steamer begins producing steam, set the Timer for the appropriate amount of time needed for the client's skin type.

Normal Time Settings for Various Skin Types: Normal Skin – 8 – 10 minutes

Oily Skin – 12 – 15 minutes Sensitive/Dry Skin – 3-5 minutes Rosecea or couperose (broken capillaries) – 3-5 minutes

Precaution: You should never turn the timer on unless the jar is in place and has water in it. Starting the heating element without water in the tank may damage the steamer.

2. Steam created by distilled water is practically invisible. To guide the steam to client's face, push the Ozone Button. The Aromatic Economy Steamer will produce a small amount of ozone, which has a germicidal effect.

Note: Unless the Ozone is turned on, you may not be able to see the steam. The ozone should be turned on during the last five minutes of the treatment.

Note: When the water drops below a safe level, the Aromatic Economy Steamer will cut off. It may need to cool down enough that the overheat sensor can reset itself. You will have to refill it with water before you can resume treatment. **Do not add cold water to the hot steamer jar**.

- 3. Never position the Aromatic Economy Steamer so that the nozzle is closer than 16" from the face. If the client has large couperose areas or their skin is overly sensitive, you may have to move it farther away. If the skin is thick or oily, you can move the nozzle closer to the face.
 - The arm does not move. It is a stationary arm. However, the nozzle will move 180° left or right. There are built-in stops. Do not force.
 - To move the unit around the room, grab the handle. Do not pull on the Power Cord.
- 4. When treatment is finished, turn off Aromatic Economy Steamer.
- 5. Unplug the unit when not in use.

To use the Aromatic Economy Steamer With Aromatherapy.

- 1. *Do not* add any oils (such as essential oils for aromatherapy) in the steamer jar. Oils may be placed on a felt strip and placed inside the Aroma Cap.
- 2. Unscrew the ring that surrounds the Nozzle at the end of the Steamer Arm.
- 3. Put a few drops of an essential oil on a felt strip. The amount of oil you use will depend on the aromatic strength of the oil.
- 4. Tuck the felt strip in the groove inside the nozzle.
- 5. Replace the ring and tighten.

Suggestion: When changing oils –remove the felt strip and place it in a plastic bag, label with the scent and put in the freezer for future use.

Cleaning Instructions

1. Wash the glass jar every day. Rinse thoroughly. Do not leave any soap residue in the jar.

Note: When you remove the jar, make sure you remove the gasket also. If you don't, it may drop down on the heating element.

2. Wipe the heating element dry every day.

- 3. Do not use metal brushes to clean the heating element.
- 4. Once a week, the glass jar and heating elements should be cleaned with a solution of distilled water and white vinegar (one part vinegar to three parts water). Soak the jar in the vinegar solution for 2-3 hours.

Authorized Technical Service Center:

Universal Companies, Inc. 18260 Oak Park Drive Abingdon, VA 24210 Phone: 1-800-558-5571 Fax: 1-800-237-7199 E-Mail: info@universalcompanies.com