

Mini 209Clean Cabi

Instruction Manual

Function:

The **Mini 209Clean Cabi** provides a clean, germ-free environment for storage of sterilized implements and tools.

This useful clean cabinet, with UV germicidal lamp, provides an optimum environment for storage of sterilized surgical equipment, scissors, clippers, stainless steel cuticle pushers, fingernail and pedicure tools, etc.

Operating Instructions:

1. Press the "Power" switch to turn on unit.
2. Allow cabinet to run for 5 minutes before placing anything inside.
3. After 5 minutes, place sterilized implements in cabinet.
4. For best cleaning results, keep implements inside cabinet for one hour with ?Power? switch on.
5. After one hour, implements are ready for use.