

Small Tray Disinfectant System

Read disinfectant instructions thoroughly. It is a violation of Federal Law to use a product in a manner inconsistent with its labeling

Usage

1. Remove the tray system from shipping packaging and discard.
2. Open the tray system and remove the basket.
3. Fill Ultra-Tray with water to the indicator mark (square shaped box).
4. Add 1/8 oz. of Ultrasonics 10 minutes Instrument Disinfectant or 1/4 oz. Ultracare Disinfectant (small bottle supplied with system).
5. Replace instrument basket in tray.
6. Thoroughly clean and rinse instruments and place into basket.
7. Close cover to submerge instruments.
8. Remove after 10 minutes, rinse and wipe dry.
9. If using Ultrasonics 10 minutes system, do not soak stainless steel implements, prolonged soaking may cause damage to instruments.
10. Plastic may remain immersed until ready to use.
11. Store in dry covered container or closed drawer.
12. Change solution daily or as solution permits.