

Instruction Manual for



SE0012 - Fleece Table Warming Pad and SE0013 - Deluxe Fleece Table Warming Pad

Fleece Table Warming Pad

5 Heat Settings, Adjustable timer

IMPORTANT – INSTRUCTIONS – DO NOT DESTROY

IMPORTANT: Please read the enclosed USER MANUAL for ALL safety and operational instructions and information on our limited warranty. Keep it for reference as long as you own this product. Do not discard.

Warning: To operate this Heated Blanket properly and safely, there are some critical safety precautions you need to follow. As with all electrical appliances, there is an inherent danger of overheating, fire, or personal injury if the product is not used correctly. Please read what follows before using your warming product.

General Instructions

Congratulations on the purchase of your new massage table warmer. Before first using your new table warmer, it is important that you read all instructions carefully, even if you are familiar with the appliance.

1. Your massage table warmer should be placed directly on the massage table with the power lead near the upper body.
2. Ensure that the table fits your massage table.
3. To attach the table warmer to the massage table follow instructions below titled “How to Secure your Massage Table Warmer.” Keep your massage table warmer flat and avoid unnecessary wear by crumpling.
4. The Table Warmer is sized to give even, all over warmth for the remainder of the massage table surface. The table warmer should not be tucked in at the sides.
5. When securely attached to the massage table, connect the plug to the power point and switch on. The flexible cord and switch must be kept outside the massage table and away from open windows or exposure to moisture.
6. We recommend that the cord switch is set to the higher position for half an hour before using and then can be turned down to the low setting or off altogether depending on your requirements while using the massage table.

KEEP YOUR TABLE WARMER FLAT AND FULLY SPREAD OUT WHEN SWITCHED ON. FAILURE TO OBSERVE THESE INSTRUCTIONS WILL CAUSE OVERHEATING.

How To Secure Your Massage Table Warmer

1. Place table warmer on the massage table.
2. The table warmer should be firmly secured to the massage table using the provided elastic bands.
3. Must only be used with the original controller, using controllers from other massage table warmers may damage your product.
4. Used only as an under blanket.

Overheat Safeguard System

All Massage Table Warmers come fitted with our Overheat safeguard system. This safeguard system offers protection against overheating or damage to the element by disengaging the power to the heating element before any over heating hazards occur.

IMPORTANT

Check daily that your table warmer is flat, fully spread out and secured before switching on.

FAILURE TO OBSERVE THESE INSTRUCTIONS WILL CAUSE OVERHEATING. OVERHEATING WILL ACTIVATE OUR OVERHEAT SAFEGUARD SYSTEM, THUS LEAVING THE TABLE WARMER INOPERATIVE, VOIDING ALL WARRANTIES.

1. Use as an under blanket only.
2. This table warmer is not recommended for use on an adjustable bed, if used on an adjustable bed, check that the blanket or cord cannot become caught.
3. Make sure that the heating area (element) on any side of the massage table does not hang over the edge of the table; that the means of attachment are adequate and suitable for the particular massage table; and that the instructions are read carefully before using the table warmer.
4. The appliance is not intended for use by young children or elderly persons without supervision. For human use only, not pets.
5. Young children should be supervised to ensure that they do not play with the appliance.
6. Prolonged application at the high setting can result in skin burns.
7. Do not tuck in.
8. Do not use tucked or folded.
9. Keep the control unit away from an open window.
10. Do not use pins-they may damage the electric wiring.
11. Be sure that this table warmer is used only on an alternating current supply circuit of the proper voltage.
12. The supply power cord and switch must be kept as far as possible from the massage bed.
13. Do not switch the power on if the table warmer is wet or in a folded stated.
14. Switch off at the power outlet and remove the plug when your table warmer is not in actual use.
15. This table warmer must be kept in the fully spread condition at all times during use to avoid overheating. It is imperative that the table warmer is frequently inspected to ensure that the table warmer is being well maintained.
16. Bedclothes should not be folded back when the table warmer is switched on. Do not leave heavy objects on the massage table when the unit is turned on, e.g. folded blankets, or suitcases.
17. Arrange the table warmer so that it is not beneath pillows and bolsters.
18. Do not launder or dry-clean this table warmer. Cleaning liquid may have a deleterious effect on the insulation or covering of the heating unit.
19. Persons suffering from bed-wetting should not use this massage table warmer.
20. If any abnormality or defect in the operation of this table warmer is observed, discontinue its use immediately and consult the manufacturer or the supplier regarding its repair.
21. The table warmer should frequently be examined for signs of wear, either of the blanket, controller the power cord. If wear is visible, the table warmer should be returned immediately to manufacturer or supplier for inspection and overhaul. Servicing, by law, must be undertaken by a qualified and registered person.

22. It is recommended you follow instructions for localized soiling if a small amount of soiling occurs.
23. The table warmer must not be used over or under a water bed.
24. You may notice a blue flash in the switch when it is moved from one setting to another. This is NOT dangerous and it is only the copper parts making contact.
25. We recommended that your table warmer is inspected by a qualified and registered person after three years of use.
26. When storing, fold neatly but not tightly (or roll) without sharp bends in the heating element and store where no other objects will be placed upon it.
27. Avoid pressing creases into the appliance.
28. This appliance is for domestic use only. Not intended for use in hospitals.

Note: No user serviceable parts inside. Unauthorized modification voids warranty. Return to place of purchase for replacement or service under warranty.

Compulsory Warning

If the supply cord is damaged, it must be discarded.

Recommended Cleaning Instructions

Treatment for Localized soiling: Switch the unit off and unplug. The area affected should be sponged gently using a natural wool detergent or mild soap flakes with lukewarm water, followed by two sponges with clean lukewarm water. Lightly compress the treated area between two towels to absorb excess water, and spread out flat to dry in a shady area. This table warmer should not be hung to dry.

The connections to the blanket should be kept free of moisture as much as possible.