

Digital Thermometer

This thermometer can be used for testing the temperature of the oil used in Shirodhara treatments, to test the water temperature in stone heaters, or to test the temperature in any other spa warming unit.

Benefits

- ◆ Easy to read
- ◆ Updates every 1 second

Procedure

How to Start

1. Press **On/Off** to start.
2. Select Celsius or Fahrenheit by pressing **C/F** button on rear.
3. Insert probe for instant temperature reading.

Min/Max Memory

1. Press **Min/Max** to read the highest/maximum temperature reached.
2. Press **Min/Max** again to read the lowest/minimum temperature reached.

To Erase Readings

1. Press **Min/Max** to see Maximum reading, and then press **Clear**.
2. Press **Min/Max** again to see Minimum reading, and then press **Clear**.

Precautions

- ◆ When inserting temperature into substance to be measured, leave 1" (2.5 cm) distance between the surface of the product and the LCD unit.
- ◆ Do not expose LCD unit to temperatures over 190° F (88° C). Only the probe can be exposed to temperatures over 190° F.
- ◆ **Not for use in ovens or other heating equipment - damage may result.**

Cleaning

- ◆ Gently wipe clean with a soft cloth and mild detergent only.
- ◆ Rinse probe without wetting the LCD unit.
- ◆ **Never use abrasives.**

Specifications

- ◆ Sensor Temperature Range: 14°F to 392°F (-10°C to 200°C)
 - ◆ Unit Operating Temperature: 14°F to 190°F (-10°C to 88° C)
 - ◆ Resolution: 0.1°F (0.1°C)
 - ◆ Accuracy: ±1.8°F (14° to 180°F range) ± 1.0°C (-10°C to 82° C)
 - ◆ Response Time: Updates every 1 second
 - ◆ Probe: 4.25" (107 mm) Stainless Steel
 - ◆ Battery: 1.5 V button
-