



PARAGON® IOI FACIAL VAPORIZER

Before installing and using this unit, please carefully read these instructions. Be sure to keep this available for later reference.

UNPACKING

Unpack carefully. There are glass parts. BE SURE TO REMOVE ALL FOAM PACKING FILLER BEFORE APPLYING POWER TO THE UNIT. Check to ensure that the following items are included.

- Steamer top, assembled complete with:
 - o Glass Beaker (101-25)
 - o Silicon Gasket (101-27)
 - o Complete Brace (101-BRAC)
 - No Drip Nozzle (101-NOZL)
- Roller Stand, assembled with:
 - o 5 Roller Casters (101-23)
 - o Leg Assembly (101-24)
 - Height Adjust Pole w/ Knob

WARNING

USE ONLY DISTILLED WATER WITH THIS MACHINE. DISTILLED WATER SHOULD BE USED TO HELP PROLONG THE LIFE OF THE MACHINE. DO NOT RUN CHEMICALS THROUGH THE APPLIANCE SUCH AS CLEANING AGENTS OR AROMA ADDITIVES. THESE CLOG THE WATER WAYS AND LEAVE DEPOSITS.

TO AVOID STEAMER BURNOUT DO NOT TEST RUN THE APPLIANCE DRY

TO PREVENT WATER FROM SPOUTING - ALWAYS MAINTAIN THE DISTILLED WATER LEVEL AT THE PROPER LEVEL BETWEEN THE TOP AND BOTTOM RED LINES.

TO EXTEND THE LIFECYCLE OF THE HEATING ELEMENT AND TO PREVENT THE GLASS JAR FROM CRACKING, DO NOT ADD COLD WATER WHILE WATER IS HOT. WAIT FOR WATER TO COOL BEFORE ADDING MORE WATER.

CAUTION: DO NOT ATTEMPT TO REMOVE OR INSERT THE GLASS JAR WHEN HOT, DURING USE, OR IMMEDIATELY AFTER USE.

BEFORE TURNING ON THE STEAMER, FILL THE WATER JAR TO THE TOP RED LINE. DO NOT OVERFILL ABOVE TOP RED LINE.

DAILY MAINTENANCE

Steamer should be cleaned and inspected on a daily basis or once before each day's use.

- A. Check to see that the steamer is in good working condition and that there no are exposed parts or wires.
- B. Check that the steamer is securely mounted on its stand.
- C. Check for broken jars, parts, and etc.

OPERATION

- A. Remove glass jar. Hold the jar with one hand and use the other hand to simultaneously turn the retaining screw knob. Swing the brace away and carefully remove the glass jar.
- B. Check for the gasket resting atop the glass jar. Its function is to help seal the water jar and to prevent water from leaking.
- C. Pour distilled water into the glass jar. To prevent water from spouting do not to exceed the top red line.
- D. Turn the timer knob to the desired time setting.
- E. Wait 7-10 minutes for steam to appear. Wait until the steam is a steady fine mist before directing the steam towards the client.
- F. Turn the ozone switch on as needed.
- G. Cover the client's upper chest area with towel or cloth to absorb excess moisture.
- H. Adjust the steam nozzle to the desired direction, keeping a minimum distance of 12 inches from face. Let the steam flow out in an upward direction traveling from the customers' chest and up

AROMA THERAPY NOZZLE (Item No. AT-1)

The AT-1 Aroma Therapy Nozzle is an optional item that can be easily attached to the steamer nozzle for the use of aromatic therapy oil. This allows the client to experience the benefits of aromatic oils while simultaneously protecting the steamer from clogging and spouting.

OZONE

Ozone is a form of oxygen sometimes used as a form of disinfectant. The ozone function in the facial steamer is an option. Check with applicable regulatory agencies such as the Department of Health and the Cosmetology State Board concerning the use of ozone in your area. To activate the ozone function, use the on/off switch located next to the timer knob. When ozone is in use, the green activate lamp will light up.

MAINTENANCE

All appliances should be cleaned once a week.

- A. A safety check should be performed before the start of each day's use. If unit is unsafe to use or needs repair, please call the manufacturer for instructions on how to send your machine in for service.
- B. Only distilled water should be used in the Vaporizer. The use of tap water will eventually cause malfunction of the machine, due to calcium and mineral deposits.
- C. Do not use harsh chemical to clean the appliance. Use a soft brush to clean heating elements.
- D. Always maintain the distilled water level above the lower red line and below the top red line. In order to protect the heating element from burning out, the appliance has a safety feature installed. The low water level sensor safety fuse will shut off the appliance if the water is below the lower red line marked on the water jar. If the water is constantly below the lower red line, the low water level sensor safety fuse may burn out.

TROUBLE SHOOTING

When machine fails to work properly, use the following directions to detect the cause of the problem:

- A. Check the power cord for proper connection.
- B. Make sure the water level is between the top and bottom red lines. The steamer will beep when there is improper water level.
- C. Check the power source by connecting another electrical appliance to the AC outlet.
- D. Restart the steamer. Move the timer know to the OFF position. Wait 5-10 minutes before turning the steamer back on.
- E. If water is leaking, wait until the jar is cooled, then try to tighten the retaining screw located beneath the jar. Check that the gasket ring is atop the water jar.
- F. Some units are equipped with a heat-sensing thermostat safety fuse. If your unit(s) becomes too hot or if the water level falls below the red line, the thermostat will shut off the heating element. After cooling to the proper temperature, the element will operate normally. Wait until both the heating element and glass jar cools before adding water.
- G. If the water level is below the lower red line, the thermostat may burn out. If the thermostat has burned out, the power lamp will not light and the steamer will not turn on. Please contact an authorized agent for repair.
- H. If the problem persists, please contact your dealer for assistance. To prevent an electrical shock, PLEASE DO NOT TAKE THE MACHINE APART.

WARRANTY

- A. 1-Year warranty against manufacture defect
- B. The glass jar is not a warranty item
 C. The thermo (low-water level) sensor safety-fuse is not a warranty item.

1	20	٧,	78	30V	٧, 6	.5ar	nps
---	----	----	----	-----	------	------	-----

Questions or Comments?
Please call 1-888-731-6688
www.garfieldint.com

	ATTENTION	
For your protection in the event of theft	or loss of this product, please fill in the information below for you own person	al records.
Model No	Serial No(Located on back or bottom side of unit.)	
Date of Purchase	Dunck and Duice	
Purchased From		

ASSEMBLY - ROLLER BASE (item no 101-20)




Fig. 6





PARAGON[®] 186, 186/52 MAG LAMP

Before installing and using this unit, please carefully read these instructions. Be sure to keep this available for later reference.

1 UNPACKING

Unpack carefully. This lamp has glass pieces.


BE SURE TO REMOVE ALL PACKING MATERIAL BEFORE APPLYING POWER TO THE UNIT.

2 ASSEMBLY

2.1 Mobile Stand Model No. 52

Check that you have the enclosed parts:

- Metal Pole w/ Spring Washer and Nut
- Metal Rectangular Cross Bars (2pcs)
- Caster Wheels (4pcs)




- A. Unscrew the preassembled spring washer and nut from the bottom of the metal pole.
- B. Place the rectangular cross bars perpendicular to one another. Check to see that the predrilled holes for the caster wheels are facing down.
- C. Place pole into center hole of base and screw the nut and spring washer to the base of the pole. Tighten the nut with a hand wrench.
- D. Insert the lamp stem into the top of the pole.

Please note, the table clamp is not included for units ordered in combination with the mobile stand.

2.2 Table Clamp Model No. 186-CC

NOTE: The c-clamp is designed to be used on a level surface and should only be mounted onto a sturdy piece of furniture or other permanent fixtures.



- A. "Open" the metal clamp by turning the sliding pin handle counterclockwise.
- B. Position the table between the screw swivel end and the padded clamp anvil.
- C. "Close" the clamp by turning the sliding pin handle. Tighten until securely fastened.
- D. Insert the lamp stem into the top of the pole.

3 MAINTENANCE

3.1 Maintenance

Lamps should be cleaned and inspected on a daily basis or once before each day's use.

- A. Check to see that the lamp is in good working conditions and that there are exposed parts or wires.
- B. Check that the lamp is securely mounted on its stand or clamp.
- C. Check for broken bulbs, lens, and etc.

3.2 Bulbs

This lamp uses a 22W cool fluorescent circline lamp. For replacement bulbs, please visit your local hardware store or contact your distributor. The following are instructions for replacing a broken bulb.

- A. CAUTION! Use caution when removing broken bulbs. There may be broken glass. Broken glass may cut.
- B. Unplug the lamp and carefully remove from the lamp from its stand or clamp.
- C. Lay the lamp with the clear cover face up. Unscrew (3 screws) and remove the lamp cover.
- D. If necessary, empty the contents of the lamp case.
- E. Remove the broken bulb by gently tugging on the protected area of the bulb. Install the new bulb by inserting the 4-prong plug into its receptacle.
- F. Replace the lamp cover by securing the 3 screws.
- G. Carefully lift the lamp and replace the lamp stem into its stand or clamp.

4 TROUBLESHOOTING

When machine fails to work properly, use the following directions to detect the cause of the problem:

- A. Check the power cord for proper connection.
- B. Make sure the switch is in the ON position.
- C. Check the power source by connecting another electrical appliance to the AC outlet.
- Check that the bulb is in good working condition. You may need to switch to a new bulb.
- E. Check that the starter is securely screwed in.

5 WARRANTY & SERVICE

5.1 Warranty

One Year Limited Warranty. See attached terms and conditions for details.

5.2 Service

If the unit ever needs repair service or parts, the customer should contact the distributor or call Paragon Technical Support 1(888) 731-6688.

Electrical: 120 Volts AC, 48 Watts

GARFIELD INTL. CO., INC. 15977 HERON AVENUE LA MIRADA, CA 90638 PARAGON[®] is a trademark of Garfield International.



Questions or Comments? Please call 1-888-731-6688



www.garfieldint.com

ATTENTION

or valur protection in the eve	ent of theft or loss of this pro-	duct inlease fill in the inf	formation below for you	own personal records

Model No	Serial No(Located on back or bottom side of unit.)	
Date of Purchase	Purchase Price	
Purchased From		